



- NOTE.
1. IT IS PREFERRED TO CUT POTENTIOMETERS BEFORE ASSEMBLY.
  2. THE POTENTIOMETERS FIXING NUT & METAL WASHER IS INTENDED TO BE FIXED TO THE OUTSIDE OF A PLASTIC ENCLOSURE, NOT THE BOTTOM OF THE PCB, OTHERWISE YOU WILL NEED AN INSULATING SPACER TO PREVENT A SHORT WITH THE PCB TRACK.

